

Detectamet Data Sheet / Instruction for use

Applicable Products:

Product Code:	Product Description:
605-T042-P01	Pocket Knife Lockable Detect Handle Lambfoot Blade Blue
605-T043-P01	Pocket Knife Lockable Detect Handle Sheepfoot Blade Blue
605-T044-P01	Pocket Knife Lockable Detect Handle Clip Point Blue
605-T045-P01	Pocket Knife Lockable Detect Handle Pruning Blade Blue



Description:	Heavy Duty Locking Action Knife
Blade:	Taper ground 420S45 Stainless Steel hardened to 51-55 Rockwell C
Handle:	Detectamet metal detectable plastic
Origin:	Made in Sheffield

General Instructions for Use

Keep the blade sharp. Keep the knife clean and dry. Keep the working parts lightly oiled using a good quality mineral oil. Always cut away from you. Use only for purpose for which it is intended.

Don't throw the knife. Don't use as a lever, pry bar, hammer, chisel or wedge.

Always work safely with tools and wear approved eye protection. Never use near live electrical circuits.

Lock Instructions

This knife features a blade which locks into the open position to minimise the risk of it accidentally closing while in use. The lock is released by carefully pushing the locking-lever away from the base of the blade before folding the blade back into the handle.

Sharpening Instructions

To maintain the edge the blade must be sharpened correctly. The blade should be sharpened on an oilstone or a sharpening steel at an angle of approximately 20° to the stone or steel and not flat. The edge should be drawn across the sharpener from heel to point, taking alternate sides, using firm steady strokes becoming lighter when finishing. For best results sharpen little and often.

Guarantee

Our products are made by craftsmen from the finest materials and will be replaced if found to be defective when used under normal conditions. Faults resulting from free issued plastic material are not our responsibility.

No warranty is given or implied with respect to this information or patent infringement. Detectamet Ltd do not accept liability for loss or damage arising from the use of this information. Results are based on a test sample, our general experience and information from our suppliers. Data and results must be confirmed by the buyer by testing for its intended conditions of use.



www.detectamet.co.uk

T: +44 (0)1759 304200 | F: +44 (0)1759 305236
E: sales@detectamet.com

Detectamet Ltd

Company Registration No. 5103699
VAT Registration No. GB 842 411357

Prospect House, 1 Halifax Way, Pocklington Ind. Estate
York, YO42 1NR, United Kingdom