

Technical Data Sheet



1. Product

163.1 - J-QUANT Chlorine 300 mg/L, 100 strips/pk

2. Instructions for use

- Immerse an indicator strip in the test solution for 1 second.
- Shake off excess solution.
- Wait 60 seconds.
- Compare the colour produced on the strip against the colour chart.

3. Measuring range

0 - 25 - 50 - 100 - 200 - 300 mg/L



4. Application

The J-QUANT Chlorine test strip detects residual chlorines, for example, in drinking water, pools, and hot tubs where chlorine may be used as a disinfectant.

5. Shelf Life

3 years from manufacturing date.

6. Contents

100 strips

7. Weights & Dimensions

Strip dimension: 83mm x 5mm

8. Notes

Keep any unused strips in the original container. Do not store where they are liable to be exposed to acid or alkaline gases or vapours. Store in a cool dry place.