

# Technical Data Sheet



## 1. Product

161.1C - J-QUANT Chlorine 5 mg/L, 100 strips/pk

## 2. Instructions for use

- Immerse an indicator strip in the test solution for 10 seconds.
- Shake off excess solution.
- Wait 10 seconds.
- Compare the colour produced on the strip against the colour chart.

## 3. Measuring range

0 - 0.5 - 1 - 3 - 5 mg/L



## 4. Application

The J-QUANT Chlorine test strip detects residual chlorines, for example, in drinking water, pools, and hot tubs where chlorine may be used as a disinfectant.

## 5. Shelf Life

3 years from manufacturing date.

## 6. Contents

100 strips

## 7. Weights & Dimensions

Strip dimension: 83mm x 5mm

## 8. Notes

Keep any unused strips in the original container. Do not store where they are liable to be exposed to acid or alkaline gases or vapours. Store in a cool dry place.

**Johnson Test Papers Ltd**  
Hainge Park, Hainge Road  
Oldbury, West Midlands  
B69 2NU, United Kingdom

**T:** +44 (0)121 557 3883  
**F:** +44 (0)121 557 8235  
**E:** [info@jtp.uk.com](mailto:info@jtp.uk.com)  
**W:** [www.johnsontestpapers.com](http://www.johnsontestpapers.com)

Registered in England  
Company Reg No: 4112470  
VAT No: GB 754 6913 04

