

# Technical Data Sheet



## 1. Product


185.1 - J-QUANT Water Hardness 0 - 500 mg/L, 100 strips/pk

## 2. Instructions for use

- Immerse an indicator strip in the test solution for 2 seconds.
- Shake off excess solution.
- Wait 10 seconds.
- Compare the colour produced on the strip against the colour chart.

## 3. Measuring range

0 - 50 - 125 - 250 - 500 mg/L (as  $\text{CaCO}_3$ )



## 4. Application

The J-QUANT Water Hardness test strips is used for testing total hardness in water.

## 5. Shelf Life

3 years from manufacturing date.

## 6. Contents

100 strips.

## 7. Weights & Dimensions

Strip dimension: 83mm x 5mm.

## 8. Notes

Keep any unused strips in the original container. Do not store where they are liable to be exposed to acid or alkaline gases or vapours. Store in a cool dry place.